



SHIFTER INSULATION KIT, NA/NB 21-67319



Thanks for purchasing our shifter insulation kit. If you have any questions during installation or suggestions for improvement to the product or the instructions - please don't hesitate to call or email.

WARNING: Not everyone can perform every installation. It is critical that you be honest with yourself in regards to your ability. We're more than happy to help, but there are only so many things we can do from the other end of a phone / computer. If in doubt, discuss the install with us before you dive in. Improper installation could cause injury and / or death!

Required tools:

- Phillips screwdriver
- Small flat-blade screwdriver
- Non-marring trim panel tools (NB only)
- Needle nose pliers

1. On the center console, remove the screw on each side where the front of the console joins the dash (1). NB screws are covered by a trim cap that can be popped open with a small flat-blade screwdriver.

2. Gain access to a hidden screw by removing the cupholder or ashtray on an NA (2) or the power window switch on an NB (2). Then remove the screw.

NBs only: To remove the window switch, use non-marring trim panel tools to gently lift up on the front or rear edge of the switch. Be careful, as it is relatively easy to break the retaining tabs. Once removed, unplug the window switch. Use needle-nose pliers to pinch the window switch's harness retaining tab directly beneath the switch.

3. Remove the last two screws from within the console's storage compartment (3). Remove the shift knob by unscrewing it and remove the console.

4. Install the lower portion of the insulation with the grey side up and the two flat edges pointing forward and to the right, as shown (4). Ensure it is fully seated around the large rubber shift boot. Install the upper portion of the insulation.

5. Reassembly happens in the opposite order of the removal.

