



For the best results when cutting Wall Tiles or Hanging Panels, please adhere to the following guidelines.

- Use a clean, sharp tool for the cleanest and smoothest cuts. Change blades frequently to avoid fraying.
- Mark cut lines with a pencil or tape. Use a ruler when cutting for clean and straight cuts.
NOTE: pencil lines are not easily removed on felt.
- Secure panels tightly to avoid slippage while cutting.
- Do not heat felt or tools when cutting to prevent uneven, melted edges
- Do not use lasers, routers, or spiral cutters to cut felt.

Utility Knife

Use a straight edge or utility knife. Ensure the blade is sharp and clean for the best results. Recommended only for small, precise cuts.

Hand Saw

Use a sharp, fine-toothed saw and cut with slow, even strokes at a low angle.

Table or Circular Saw

Use a sharp, fine-toothed saw and guide the panel across the saw with even pressure. When cutting multiple panels, multiple blades are recommended.

Jig Saw

Use a sharp, fine-toothed blade and cut with slow, steady movements. Ensure not to overhead an area with the blade

NOTE: Warranty does not apply to:

- Customer modifications to the product
- Any product that has been modified, altered, tampered with or repaired by any person other than an authorized representative of AMQ Solutions